SELEC

OP625-V0

MFM284

Operating Instructions

SELEC	MFM284
4 15. 5.00 (00 (165432	

72 X 72

SPECIFICATIONS

DISPLAY

Liquid crystal display with backlight 4 lines, 4 digits per line to show electrical parameters 5th line, 8 digits to show energy

LCD INDICATIONS

- Communication in progress ÷ MAX DMD - Maximum and Minimum Demand Power - For Total harmonics distortion THD IM - Import Energy EP - Export Energy

WIRING INPUT

3 Ø - 4 wire, 3 Ø - 3 wire, 2 Ø - 3 wire and

1 Ø - 2 wire system (Programmable as P1,P2,P3)

RATED INPUT VOLTAGE

11 to 300V AC (L-N) ;

19 to 519V AC (L-L) ; Installation Category III (600V) FREQUENCY RANGE

45-65 Hz

RATED INPUT CURRENT

Nominal 5A AC (Min-11mA, Max-6A) BURDEN

0.5 VA@5A per phase

CT PRIMARY

1A / 5A to 10,000A (Programmable for any Value) Note: 1A to 10,000A if CT secondary is 1 else CT primary is 5A to 10,000A

CT SECONDARY

1A or 5A (programmable)

PT PRIMARY

100V to 500kV (Programmable for any value)

PT SECONDARY

100 to 500V AC (L-L)(Programmable for any value) Display update time

1 sec. for all parameters

Display Scrolling

Automatic, Default or Manual (Programmable) POWER CONSUMPTION

Less than 8VA

ENVIRONMENTAL CONDITIONS

- Indoor use
- Altitude of up to 2000 meters
- Pollution degree II
- Temperature : Operating : -10°C to 55°C Storage : -20°C to 75°C
- Humiditv : Up to 85% non-condensing
- **PROTECTION CLASS : II**

MOUNTING : Panel mounting

OUTPUT

Pulse Output : Voltage range : External 24V DC max. Current capacity : 100mA max Pulse Width : 100 ms ± 5ms(Programmable

depending upon CT x PT Ratio.)

ORDER CODE INFORMATION

Product	Supply		Certification	
MEMOOA OF DALLO	85 to 3270V AC, -15% + 12%, 50 / 60Hz, ±5%		CE	
Installation Category III				
SERIAL COMMUNICATION				
Interface standard and protocol		RS485 and MODBUS RTU		
Communication address		1 to 255		
Transmission mode		Half duplex		
Data types		Float and Integer		
Transmission distance		500m maximum		
		300 600 1200 2	2400 4800	

Transmission Speed	300, 600,1200, 2400, 4800, 9600,19200 (in bps)
Parity	None, Odd, Even
Stop bits	1 or 2

ACCURACY :				
Measurement	Accuracy			
Voltage V _{L-N}	±0.5% of Full scale			
Voltage V _{L-L}	±0.5% of Full scale			
Current	±0.5% of Full scale			
Frequency	±0.1% For L-N Voltage >20V, For L-L Voltage >35V			
Active Power	1%			
Apparent power	1%			
Reactive Power	1%			
Power factor	±0.01			
Active energy	Class 1			
Reactive energy	Class 1			
Apparent energy	Class 1			
MAX / MIN Active Power	1%			
MAX / MIN Reactive Power	1%			
MAX Apparent Power	1%			

RESOLUTION :		
PT Ratio x CT Ratio	kWh / kVAh / kVArh	Pulse
<15	0.01K	0.01K
<150	0.1K	0.1K
<1500	1K	1K
<15000	0.01M	0.01M
<150000	0.1M	0.1M
≥1500000	1M	1M

NOTE: 1) For Voltage, Current and Power, resolution is automatically adjusted.

2) For power factor, resolution is 0.001

▲ SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

- Do not use the equipment if there is any mechanical damage.
- · Ensure that the equipment is supplied with correct voltage.

CAUTION :

- 1. Read complete instructions prior to installation and operation of the unit.
- 2. Risk of electric shock.
- 3. The equipment in its installed state must not come in close proximity to any heating sources, oils, steam, caustic vapors or other unwanted process by products.

WIRING GUIDELINES

WARNING :

- 1. To prevent the risk of electric shock, power supply to the equipment must be kept OFF while doing the wiring arrangement.
- 2. Wiring shall be done strictly according to the terminal layout. Confirm that all connections are correct.
- 3. Use lugged terminals.
- 4. To reduce electromagnetic interference use of wires with adequate ratings and twists of the same in equal size shall be made with shortest connections.
- 5. Layout of connecting cables shall be away from any internal EMI source.
- 6. Cable used for connection to power source, must have a cross section of 0.5mm² to 2.5mm² (20 to 14AWG ; 75°C (min)). These wires shall have current carrying capacity of6A.
- 7. Copper cable should be used (Stranded or Single core cable).
- 8. Before attempting work on device, ensure absence of voltages using appropriate voltage detection device.

INSTALLATION GUIDELINES

CAUTION :

- 1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
- 2. Conductors must not come in contact with the internal circuitry of the equipment or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
- 3. Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
- 4. Before disconnecting the secondary of the external current transformer from the equipment, make sure that the current transformer is short circuited to avoid risk of electrical shock and injury.
- 5. The equipment shall not be installed in environmental conditions other than those mentioned in this manual.
- 6. The equipment does not have a built-in-type fuse. Installation of external fuse of rating 275V AC / 0.5Amp for electrical circuitry / battery is highly recommended.

MECHANICAL INSTALLATION

- For installing the meter
- 1. Prepare the panel cutout with proper dimensions as shown below.
- 2. Push the meter into the panel cutout. Secure the meter in its place by fitting the clamp on the rear side. Fit clamps on both sides in diagonally opposite location for optimum fittina.
- 3. For proper sealing, tighten the screws evenly with required torque.



MAINTENANCE

- 1. The equipment should be cleaned regularly to avoid blockage of ventilating parts.
- 2. Clean the equipment with a clean dry or damp cloth.

Do not use any cleaning agent other than water.



FRONT PANEL DESCRIPTION



ONLINE PAGE DESCRIPTION

There are 4 dedicated keys labelled as V/I, VAF, PF/P, E. Use these 4 keys to read meter parameters. Simply press these keys to read the parameters.

KEY PRESS	ONLINE PAGE DESCRIPTION
Press	The 1st screen : Display Line to neutral voltage of
"V/I"	Three Phase. The 2nd screen : Display line to line Voltage of
	Three Phase.
	The 3rd screen : Display Total Percantage
	Harmonics of Line to neutral voltage of three phase and avg Line to neutral Voltage.
	The 4th screen : Display Total Percantage
	Harmonics of Line to Line voltage of three phase and avg Line to Line Voltage.
	The 5th screen : Display three phase of current and Neutral Current.
	The 6th screen :Display Phase Maximum Current Demand of three phase and Avg phase Current.
	The7th screen : Display Total Percentage Harmonics of current of three Phase and Avg Phase Current
	The 8th screen :Press for 3Sec.Displays Voltage sequence detection.
	Note : 1) For 3 Ø 3 wire system, for only the 2nd, 4th,5th,6th and 7th screen will be available.
	2) In 1 Ø 2 wire system only the 1nd, 3rd,5th,6th and
D	7th screen will be available.
Press "VAF"	The 1st screen : Display Voltage,current,power Factor and Frquency of 1 st Phase.
101	The 2nd screen : Display Voltage.current.power
	Factor and Frquency of ^{2nd} Phase.
	The 3rd screen : Display Voltage,current,power Factor and Frquency of 3 rd Phase.
	The 4th screen : Display Avg voltage, Current.power
	Factor and Frquency of Three phase. The 8th screen: Press for three Sec Displays
	current connection indication Page.
	Note : 1) In 3 Ø 3 wire system Avg voltage current
	power factor and freq. will be line to line. 2) In 1 Ø 2 wire system only selectabel phase
	parameter will be available.
Press	The 1st screen : Display power Factor of three
"PF/P"	phase and Avg Power Factor. The 2nd screen : Display Active Power of Three
	Phase and Avg Active Power.
	The 3rd screen : Display Reactive Power of Three Phase and Avg Reactive Power.
	The 4th screen : Display Apperant power of three
	Phase and Avg Apperant Power.
	The 5th screen : Display Total Active ,Reactive, Apperant Power and Avg Power Factor of Three Phase.
	The 6th screen : Display Max Active Power
	Demand,Max Reactive Power Demand and Max
	appearant Power Demand. The7th screen : Displaly Min Active Power Demand
	and Reactive Power Demand.
	Note : 1) For 3 Ø 3 wire system, for only the 5th,6th and 7th screen will be available.
	2) In 1 Ø 2 wire system only selectabel phase
	parameter will be available.
Press	The 1st screen : Display IMP kWh of 1 st Phase.
"E"	The 2nd screen : Display IMP kWh of 2 nd Phase. The 3rd screen : Display IMP kWh 3 rd Phase.
	The 4th screen : Display EXP kWh of 1st Phase.
	The 5th screen : Display EXP kWh of 2 nd Phase.
	The 6th screen :Display EXP kWh of 3 rd Phase. The 7th screen : Display Total IMP kWh of Three
	Phase.
	The 8th screen : Display Total EXP kWh of Three
	Phase. The 9th screen : Display Total Net kWh of Three Phase.
	The 10th screen : Display IMP kVArh of 1 st Phase.
	The11th screen : Display IMP kVArh of 2 nd Phase.

The 12th screen :Display IMP kVArh of 3rd Phase.

Press	The 13th screen : Display EXP kVArh of 1 st Phase.	1	Config. page	
"E"	The 14th screen : Display Exp kVArh of 2 nd Phase. The 15th screen : Display EXP kVArh of 3 rd Phase.			
	The 16th screen : Display Total IMP kVArh of Three Phase.	⊢	4	
	The 17th screen : Display Total EXP kVArh of	⊢	5	
	Three Phase. The 18th screen :Display Total Net kVArh of Three	⊢	6	
	Phase.	F	7	De
	The 19th screen : Dispaly kVAh of 1 st Phase. The 20th screen : Display kVAh of 2 nd Phase.	F	8	Der
	The 21th screen : Display kVAh of 3rd Phase.	┝	9	Der
	The 22nd screen : Display Total Net kVAh of Three Phase.	F	10	
	The 23rd screen : Dispaly run hour	Ļ	11	
	The 24th screen :Dispaly Auxillary interupt (How many time auxilary interupted)	L	12	
		L	13	
screen 2) For	BP3W network 19th,18th, 22nd, 23rd and 24th will be availabel. 1 phase 2 wire network, all page will be same as		14	
3 phas	e 4 wire but only selected phase		15	
AUTO	MATIC/MANUAL/DEFALT MODE DESCRIPTION	F	16	
	() button for 3 seconds to toggle between Default ,	F	17	
Note : B	ic and Manual mode. y default unit operates in Manual mode.	ſ	18	
of 5 seco	natic mode online pages scroll automatically at the rate onds per page. natic mode when any key is pressed, unit temporarily	F	19	
switches	to manual mode and the appropriate page is displayed, by key is not pressed for 5 sec, unit resumes automatic	•	19.0	
mode.		Γ	19.1	F
	It mode after 60 sec of any page, Product will shift to L-N page automatically.		19.2	R
SERIA	L NUMBER DESCRIPTION		19.3	Re
Press	PF/P (♥) key for 10sec. to display 8 digit serial	Γ	19.4	F
numbe	er only for 10sec. at 5th line of display		19.5	
CONF	IGURATION	Γ	19.6	Re
▶, ▲	ere are 4 dedicated keys with symbols marked as , ♥,◀ . use these 4 keys to enter into	•	For respassweet	ord. If

configuration menu / change setting. Note : The settings should be done by a professional, after going through this users manual and after having understood the application situation.

For the configuration setting mode :

• Use ▼ + ← keys for 3 sec. to enter or exit from the configuration menu.

• Use > keys to move curser right by one digit each time.

 Use ▲, ▼ keys for increasing and decreasing parameters value.

• Long press▲ Key and press ← key simultaneously to go back to previouse page

Page.

Config. page	Function	Range or Selection	Factory Setting	
	Password	0000 to 9998	1000	
1	Change Password	No / Yes	No	
1.1	New Password	0000 to 9998	1000	
2	Network Selection	3P4W, 3P3W, 1P2W-P1, 1P2W-P2 and 1P2W-P3	3P4W	
3	CT Secondary	1A or 5A	5	

Config. page	Function	Range or Selection	Factory Setting
4	CT Primary	1A, 5A to 10,000A	5
5	PT Secondary	100V to 500V	350
6	PT Primary	100V to 500kV	350
7	Demand interval method	Sliding / Fixed	Sliding
8	Demand interval duration	1 to 30	15
9	Demand interval length	1 to 30 min	1
10	Pulse weight (kWh)	0.01 to 99.99	0.01
11	Pulse duration (Sec)	0.1 to 2.0	0.1
12	Run Hour selection(%)	0 to 10	0
13	Slave Id	1 to 255	1
14	Baud Rate	300, 600, 1200, 2400, 4800, 9600 and 19200 (bps)	9600
15	Parity	None, Odd, Even	None
16	Stop Bit	1 or 2	1
17	Back Light	0 to 7200 sec.	0000
18	Factory default	No / Yes	No
19	Reset Energy and MAX demand	No / Yes	No
19.0	Password	0001 to 9999	1001
19.1	Reset active energy	No / Yes	No
19.2	Reset reactive energy	No / Yes	No
19.3	Reset apparent energy	No / Yes	No
19.4	Reset MAX Demand	No / Yes	No
19.5	Reset Run Hour	No / Yes	No
19.6	Reset Auxillary Interupt	No / Yes	No

g energy parameters user will be prompted the f correct password is entered, the user will be able to reset all energy parameters. This password will be value which will be greater than the configuration password by 1.

NETWORK SELECTION AND WIRING INPUT					
Network selection in Wiring configuration mode					
3P4W	3P4W, 2P3W, 1P2W (P1/P2/P3)				
3P3W	3P3W				
Note : P1, P2 and P3	Note : P1, P2 and P3 are Three Phase.				

RUN HOUR SELECTION

The value set in configuration is the percentage of current to be apply to increment run hour. If 5% is selected then after applying 5% of current run hour will increment as 0.01 at every 36 sec. If 0% is selected then run hour will increment at every 36sec even after no current is appiled.

APPLICATION OF PULSE OUTPUT



Pulse output from MFM284 meter can be interfaced into a process through a PLC for on line control of energy content in the process.

If the PLC has a self excited digital input, external DC supply is not needed.

The kWh pulse is also used to derive average kWh information at the PLC.



Pulse output from MFM284 meter can be used as alarm generator or total energy controller by interfacing it with Pre-settable counter and control circuits (Contactors, Relay, Trip Circuit).

The counter is loaded with the maximum energy consumption. When count reaches setpoint it provides output to control circuit to take appropriate action.

All fuse types : 0.5A class CC UL type 0.5A fast acting 600V

ldress	Hex Address	Parameter	Address	Hex Address	Parameter
0000	0x00	Voltage V1N	30110	0x6E	EXP kVarh3
0002	0x02	Voltage V2N	30112	0x70	Total IMP kVarh
0004	0x04	Voltage V3N	30114	0x72	Total EXP kVarh
0006	0x06	Average Voltage LN	30116	0x74	KVah1
30008	0x08	Voltage V12	30118	0x76	KVah2
30010	0x0A	Voltage V23	30120	0x78	KVah3
30012	0x0C	Voltage V31			Total Harmonic Distortion (THD)
30014	0x0E	Average Voltage LL	30124	0x7C	THD of Voltage V1N
30016	0x10	Current I1	30126	0x7E	THD of Voltage V2N
30018	0x12	Current I2	30128	0x80	THD of Voltage V3N
30020	0x14	Current I3	30130	0x82	THD of Voltage V12
30022	0x16	Average Current	30132	0x84	THD of Voltage V23
30024	0x18	kW1	30134	0x86	THD of Voltage V31
30026	0x1A	kW2	30136	0x88	THD of Current I1
30028	0x1/C	kW3	30138	0x80	THD of Current I2
30030	0x10	kVA1	30140	0x8C	THD of Current I3
30032	0x12	kVA2	30684	0x2AC	Serial No.(Data structure: Hex)
30034	0x22	kVA3			
30036	0x24	kVAr1	Formu	la to find	address of individual Harmonic
30038	0x26	kVAr2	Constan	t Paramet	ter Meaning
30040	0x28	kVAr3	Constan		Voltage V1N
30040	0x20	Total kW		0	Voltage V2N
30042	0x2C	Total kVA		1	-
30044	0x2C	Total kVAr		2	Voltage V3N Voltage V12
30040	0x2L	PF1		3	Voltage V23
30048	0x30	PF2		4	° ·
				5	Voltage V31
30052 30054	0x34 0x36	PF3 Average PF		6	Current I1
30056	0x38	Frequency		7	Current I2
30058	0x38	Total kWh		8	Current I3
30058			{143 + [(H	larmonic r	no-2) x 2] + 60 x Constant Parameter
	0x3C	TotalkVAh			
30062	0x3E	Total kVArh	For Exar	nnlo	
30064	0x40	kW MAX Active Power		npie,	
30066	0x42	kW MIN Active Power	To find th	ne 14 th Ha	rmonic address of Voltage V31
30068	0x44	kVAr MAX Reactive Power	following	formula c	can be used :
30070	0x46	kVAr MIN Reactive Power	Formula	with the n	parameter :
30072	0x48	kVA MAX Apparent Power			no-2) x 2] + 60 x C P}
30074	0x4A	MAX I1 Demand			x 2] + 60 x 5} = 467
30076	0x4C	MAX I2 Demand		ak the 1 4th	Harmonia of Voltars VO1 at 107 - 1-1
30078	0x4E	MAX 13 Demand	50, Che	JK ING 14"	Harmonic of Voltage V31 at 467 addr
30080	0x50	MAX Avg. I Demand			
30082	0x52	Run Hour			
30084	0x54	IMP kWh1			
30086	0x56	IMP kWh2			
30088	0x58	IMP kWh3			
30090	0x5A	EXP kWh1			
30092	0x5C	EXP kWh2			
30094	0x5E	EXP kWh3			
30096	0x60	Total IMP kWh			
30098	0x62	Total EXP kWh			
30100	0x64	IMP kVarh1			
30102	0x66	IMP kVarh2			
30104	0x68	IMP kVarh3			
30106	0x6A	EXP kVarh1			
	0x6C	EXP kVarh2			

Readab	le / writable pa	rameters for Communication Model Only :				
Address	Hex Address	Parameter		Range	Length (Register)	Data Structur
			Min value	Max value		
40000	0x00	Password	0	9998	1	Integer
			Value	Meaning		
40001	0x01	N/W selection	0	3P-4W	1	Integer
			1	3P-3W	1	Integer
			2	1P2W-P1	1	Integer
			3	1P2W-P2	1	Integer
			4	1P2W-P3	1	Integer
40002	0x02	CT Secondary (A)	1	5	1	Integer
40003	0x03	CT primary (CT Secondary = 5) (A)	5	10000	1	Integer
		CT primary (CT Secondary = 1) (A)	1	10000		
40004	0x04	PT Secondary (V)	100	500	1	Integer
40005	0x05	PT primary (V)	100	500000	2	Integer
40007	0x07	Slave id	1	255	1	Integer
			Value	Meaning		
40008	0x08	Baud rate (bps)	0x0000	300	1	Integer
			0x0001	600		
			0x0002	1200		
			0x0003	2400		
			0x0004	4800		
			0x0005	9600		
			0x0006	19200		
			Value	Meaning		
40009	0x09	Parity	0x0000	None	1	Intege
			0x0001	Odd		
			0x0002	Even		
40010	0x0A	Stop bit	0x0000	1	1	Intege
			0x0001	2		
40011	0x0B	Backlight OFF (sec.)	0	7200	1	Intege
40012	0x0C	Factory Default	1	Set to factory setting range	1	Intege
40013	0x0D	Reset kWh	1	Reset Total Active Energy	1	Intege
40014	0x0E	Reset kVAh	1	Reset Total Apparent Energy	1	Intege
40015	0x0F	Reset kVArh	1	Reset Total Reactive Energy	1	Intege
			Value	Meaning		
40016	0x22	Demand Interval Method	0X0000	Sliding	1	Intege
			0X0001	Fixed		
40017	0x23	Demand Interval Duration	Min Value : 1	Max Value : 30	1	Intege
40018	0x24	Demand Interval Length(min)	Min Value : 1	Max Value : 30	1	Integer
40019	0x25	Reset MAX/MIN Demand	1	Reset MAX/MIN Demand	1	Integer
40020	0x26	Reset Run Hour	1	Reset Run Hour	1	Intege
40021	0x26	Reset Auxillary Interupt	1	Reset Auxillary Interupt	1	Integer
40022	0x26	Pulse Weight (kWh)	0.01	99.99	1	Intege
40023	0x26	Pulse duration (Sec)	0.1	2	1	Intege

TYPICAL WIRING DIAGRAM



Selec Controls Pvt. Ltd., India

Factory Address : EL-27/1, Electronic Zone, TTC Industrial Area, MIDC, Mahape, Navi Mumbai - 400 710, INDIA.

Tel. No. : +91-22-41 418 419/430 | Fax No. : +91-22-28471733 Toll free : 1800 227 353 (BSNL/MTNL Subscribers only) Website : www.selec.com | Email : sales@selec.com