MRJ4M / MRJ4M-SL



SPECIFICATIONS

DISPLAY

Liquid crystal display with backlight 1 line, 4 digits and 2 line, 7 digits per line to show electrical Parameters

LCD INDICATIONS

MD - Maximum Demand of Power

🖛 - Communication in progress

LED INDICATIONS

INT - Integration of energy WIRING INPUT

- 3 Ø 4 wire, 1 Ø 2 wire
- RATED INPUT VOLTAGE
- 60 to 300V AC (L-N) ;

104 to 520V AC (L-L)

FREQUENCY RANGE

45-65 Hz

NO OF CHANNEL (For MRJ4M-SL only)

 $3 \ 0 - 2$ Channel, $1 \ 0 - 6$ Channel (Selectable) CT PRIMARY L1 and CT PRIMARY L2

(CT PRIMARY L1 for MRJ4M-SL only) 5A to 10,000A (Programmable for any Value)

CT SECONDARY

330mV

PT PRIMARY

100V to 10kV (Programmable for any value) PT SECONDARY

100 to 500V AC (L-L)(Programmable for any value) DISPLAY UPDATE TIME 1sec for all parameters POWER CONSUMPTION

Less than 8VA ENVIRONMENTAL CONDITIONS

- Indoor use

- Altitude of up to 2000 meters
- Pollution degree II

Temperature : Operating : -10°C to 55°C Storage : -20°C to 75°C

Humidity : Up to 85% non-condensing

MOUNTING : Din Rail mounting WEIGHT

MRJ4M : 191gms ; MRJ4M-SL : 200gms. OUTPUT (Valid only for 2 channel)

Pulse Output : Voltage range : 24V DC max. Current capacity : 100mA max. Pulse Duration : Selectable between 0.1 to 2.0sec. Pulse Weight : Selectable between 0.01 to 9.99kWh

ORDER CODE INFORMATION Product Supply Self Supplied(V1,N)

 Self Supplied(V1,N)
 C €

 MRJ4M
 60 to 300V AC, 50 / 60Hz, (±5%)
 ■

 MRJ4M-SL
 60 to 300V AC, 50 / 60Hz, (±5%)
 ■

 Installation
 Category III
 ■

Certification

SERIAL COMMUNICATION

Interface standard and protocol	RS485 AND MODBUS RTU
Communication address	1 to 255
Transmission mode	Half duplex
Data types	Float and Integer
Transmission distance	500 Metre maximum
Transmission speed	300, 600,1200, 2400, 4800, 9600,19200 (in bps)
Parity	None, Odd, Even
Stop bits	1 or 2
Response time	100ms (max and independent of baud rate)

RESOLUTION		
PT Ratio x CT Ratio	kWh	INT
<15	0.01K	0.001K
<150	0.1K	0.01K
<1500	1K	0.1K
<15000	0.01M	1K
<150000	0.1M	0.01M

NOTE : 1) For Voltage, Current, Power, resolution is automatically adjusted 2) For power factor, resolution is 0.01 3) For MRJ4M-SL : Total energy is highest

resolution of loads

ACCURACY :

Measurement	Accuracy
Voltage V _{L-N}	±0.5% of full Range
Voltage V	±0.5% of full Range
Current	±0.5% of full Range
Frequency For L-N Voltage >20V, For L-L Voltage >35V	±0.1% of full Range
Active Power	±1% of full Range
Apparent power	±1% of full Range
Reactive Power	±1% of full Range
Power factor	±0.01 of full Range
Active energy Class 1	IEC62053-21
Reactive energy Class 2	IEC62053-22
MAX Active Power	±1% of full Range
MAX Apparent Power	±1% of full Range

SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

- Do not use the equipment if there is any mechanical damage.
- Ensure that the equipment is supplied with correct voltage.

CAUTION :

1. Read complete instructions prior to installation and operation of the unit.

2. Risk of electric shock.

The equipment in its installed state must not come in close proximity to any heating sources, oils, steam, caustic vapors or other unwanted process by products.

WIRING GUIDELINES

WARNING :

- To prevent the risk of electric shock, power supply to the equipment must be kept OFF while doing the wiring arrangement.
- 2. Wiring shall be done strictly according to the terminal layout. Confirm that all connections are correct.
- 3. Use lugged terminals.
- To reduce electromagnetic interference use of wires with adequate ratings and twists of the same in equal size shall be made with shortest connections.
- 5. Layout of connecting cables shall be away from any internal EMI source.
- Cable used for connection to power source, must have a cross section of 0.5mm² to 2.5mm² (20 to 14AWG; 75°C (min)).
- Copper cable should be used (Stranded or Single core cable).
- Before attempting work on device, ensure absence of voltages using appropriate voltage detection device.

INSTALLATION GUIDELINES

CAUTION :

- 1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
- Conductors must not come in contact with the internal circuitry of the equipment or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
- Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
- 4. The equipment shall not be installed in environmental conditions other than those mentioned in this manual.
- 5. The equipment does not have a built-in-type fuse. Installation of external fuse of rating 275V AC / 0.5Amp for electrical circuitry / battery is highly recommended.

DIMENSIONS (All dimensions in mm)

Front View







All fuse types : 0.5A class CC UL type 0.5A fast acting 600V

CHANNEL DESCRIPTION (For MRJ4M-SL only)

		,,
LOAD	2 CH	6 CH
L1	1st, 2nd & 3rd phase of current 1	CH1, CH2, CH3
L2	1st, 2nd & 3rd phase of current 2	CH4, CH5, CH6

Doc. name : OP INST MRJ4M / MRJ4M-SL OP386-V03(Page 1 of 4)

OP386-V03

FRONT PANEL DESCRIPTION



ONLINE PAGE DESCRIPTION

There are 2 dedicated key labeled as PAGE and PRG with symbols marked as \triangleright and A to read meter parameters.

At power ON meter displays average phase to neutral voltage and active energy of three phases. If any key is not pressed for 60sec., unit resumes manual mode.

KEY PRESS	PARAMETER KEY	DESCRIPTION		
ONLINE PAGE DESCRIPTION FOR MRJ4M				
Press page (⊃) key	PressA key	Displays line to neutral voltage of three phases Displays line to line voltage		
(1st time)	Press ⊅ key 3 sec.	of three phases Displays voltage sequence.		
Press page (⊅) key (2nd time)		Displays phase current of three phases		
Press page (⊳)		Displays average phase to neutral voltage, current and power factor of three phases and frequency		
key (3rd time)	PressA key	Displays average line to line voltage, current and power factor of three phases and frequency.		
		Displays power factor of three phases and frequency.		
	PressA key 1st time	Displays active power of three phases		
	PressA key 2nd time	Displays reactive power of three phases		
_	PressA key 3rd time	Displays apparent power of three phases		
Press page (⊳) key	PressA key 4th time	Displays total active power of three phases		
(4th time)	PressA key 5th time	Displays total reactive power of three phases		
	PressA key 6th time	Displays total apparent power of three phases		
	PressA key 7th time	Displays max demand of active power		
	PressA key 8th time	Displays max demand of apparent power		
Press page (⊅)		Displays average phase to neutral voltage and active energy of three phases.		
key (5th time)	PressA key	Displays average phase to neutral voltage and reactive energy of three phases.		

KEY PRESS REAMETER KEY		DESCRIPTION		
ONLINE PAGE DESCRIPTION FOR MRJ4M-SL (2CH)				
Press		Displays line to neutral voltage of three phases		
page (⊅) key	PressA key	Displays line to line voltage of three phases		
(1st time)	Press⊅ key 3 sec.	Displays voltage sequence.		
Press page (⊳)		Displays current of three phases of load 1.		
key (2nd time)	Press A key	Displays current of three phases of load 2.		
		Displays power factor of three phases of load 1 and frequency.		
	Press A key 1st time	Displays power factor of three phases of load 2 and frequency.		
	PressA key 2nd time	Displays active power of three phases of load 1.		
	PressA key 3rd time	Displays active power of three phases of load 2.		
	PressA key 4th time	Displays reactive power of three phases of load 1.		
	PressA key 5th time	Displays reactive power of three phases of load 2.		
Press page (⊳)	PressA key 6th time Displays apparent power three phases of load 1.			
key (3rd time)	PressA key 7th time	Displays apparent power of three phases of load 2.		
	PressA key 8th time	Displays total active power of three phases of load 1 and load 2.		
	PressA key 9th time	Displays total reactive power of three phases of load 1 and load 2.		
	PressA key 10th time	Displays total apparent power of three phases of load 1 and load 2.		
	PressA key 11th time	Displays max demand of active power of load 1 and load 2		
	PressA key 12th time	Displays max demand of apparent power of load 1 and load 2		
		Displays average phase to neutral voltage and active energy of three phases of load 1 and load 2		
Press page (⊳)	PressA key 1st time	Displays average phase to neutral voltage and reactive energy of three phases of load 1 and load 2		
key (4th time)	PressA key 2nd time	Displays total active energy of three phases of Load 1 and Load 2		
	PressA key 3rd time	Displays total reactive energy of three phases of Load 1 and Load 2		
Note - For 1 p		work, all page will be same as 3 ed phase parameter will display.		

KEY PRESS	PARAMETER	DESCRIPTION
ONLINE PAG	KEY E DESCRIPTIO	N FOR MRJ4M-SL (6CH)
Press page (⊅) key (1st time)		Displays line to neutral voltage of selected phase.
Press page (⊅)		Display current of CH 1 on 1st row, CH 2 on 2nd row and CH 3 on 3rd row as page one.
key (2nd time)	Press A key 1st time	Display current of CH 4 on 1st row, CH 5 on 2nd row and CH 6 on 3rd row as page two.
		Display power factor of CH 1 on 1st row, CH 2 on 2nd row and CH 3 on 3rd row as page one & Frequency
	Press A key 1st time	Display power factor of CH 4 on 1st row, CH 5 on 2nd row and CH 6 on 3rd row as page Two & Frequency
	Press A key 2nd time	Display active power of CH 1 on 1st row, CH 2 on 2nd row and CH 3 on 3rd row as page one.
	Press A key 3rd time	Display active power of CH 4 on 1st row, CH 5 on 2nd row and CH 6 on 3rd row as page two.
	Press A key 4th time	Display reactive power of CH 1 on 1st row, CH 2 on 2nd row and CH 3 on 3rd row as page one.
Press page (⊅)	PressA key 5th time	Display reactive power of CH 4 on 1st row, CH 5 on 2nd row and CH 6 on 3rd row as page two.
key (3rd time)	PressA key 6th time	Display apparent power of CH 1 on 1st row, CH 2 on 2nd row and CH 3 on 3rd row as page one.
	Press A key 7th time	Display apparent power of CH 4 on 1st row, CH 5 on 2nd row and CH 6 on 3rd row as page two.
	PressA key 8th time	Displays total active power of load 1 (CH1,CH2,CH3) on 1st row and load 2 (CH4,CH5,CH6).
	Press A key 9th time	Displays total reactive power of load 1 (CH1,CH2,CH3) on 1st row and load 2 (CH4,CH5,CH6).
	Press A key 10th time	Displays total apparent power of load 1 (CH1,CH2,CH3) on 1st row and load 2 (CH4,CH5,CH6).
	PressA key 11th time	Displays max demand of active power of CH 1 on 1st row, CH 2 on 2nd row and CH 3 on 3rd row as page one.

KEY PRESS	PARAMETER KEY	DESCRIPTION
ONLINE PAG		N FOR MRJ4M-SL (6CH)
	PressA key 12th time	Displays max demand of apparent power of CH 1 on 1st row, CH 2 on 2nd row and CH 3 on 3rd row as page one.
Press page (⊅) key (3rd time)	Press A key 13th time	Displays max demand of active power of CH 4 on 1st row, CH 5 on 2nd row and CH 6 on 3rd row as page two.
	PressA key 14th time	Displays max demand of apparent power of CH 4 on 1st row, CH 5 on 2nd row and CH 6 on 3rd row as page two.
	_	Displays line to neutral voltage of selected phase on 1st row and CH1 active energy
	Press A key 1st time	Displays line to neutral voltage of selected phase on 1st row and CH1 reactive energy
	Press A key 2nd time	Displays line to neutral voltage of selected phase on 1st row and CH2 active energy
	PressA key 3rd time	Displays line to neutral voltage of selected phase on 1st row and CH2 reactive energy
	PressA key 4th time	Displays line to neutral voltage of selected phase on 1st row and CH3 active energy
Press page (⅀) key (4th time)	PressA key 5th time	Displays line to neutral voltage of selected phase on 1st row and CH3 reactive energy
	PressA key 6th time	Displays line to neutral voltage of selected phase on 1st row and CH4 active energy
	PressA key 7th time	Displays line to neutral voltage of selected phase on 1st row and CH4 reactive energy
	Press A key 8th time	Displays line to neutral voltage of selected phase on 1st row and CH5 active energy
	Press A key 9th time	Displays line to neutral voltage of selected phase on 1st row and CH5 reactive energy
	Press A key 10th time	Displays line to neutral voltage of selected phase on 1st row and CH6 active energy

KEY PRESS	PARAMETER Key	DESCRIPTION	
ONLINE PAG	E DESCRIPTIO	N FOR MRJ4M-SL (6CH)	
	PressAkey 11th time	Displays line to neutral voltage of selected phase on 1st row and CH6 reactive energy.	
Press page (⊅) key (4th time)	PressA key 12th time	Displays line to neutral voltage of selected phase on 1st row and total active energy of all channel.	
	Press A key 13th time	Displays line to neutral voltage of selected phase on 1st row and total reactive energy of all channel.	
Note · All pa	aac will be can	ne as above for P1/P2/P3 only	

Note : All pages will be same as above for P1/P2/P3 only phase wise voltage will be display (For MRJ4M-SL only)

SERIAL NUMBER DESCRIPTION

Press A key for 10sec. to display 8 digit serial number, the serial number will be displayed for 10 second

CONFIGURATION

There are 3 dedicated key with symbols marked as D, A and A. Use these 3 key to enter into configuration / change setting.

- **Note** : The settings should be done by a professional, after going through this users manual and after having understood the application situation. For the configuration setting mode :
- Use A and ifor 3sec. to enter or exit from config. mode.
- Use > shift key to move cursor left or right by one digit each time. After last digit of display cursor shift at 1st digit of display.
- Use A increment key for increasing the parameter value.
- Use ve to save the setting and move on to next page.
- Use A and D keys to go back and to previous page.

Config. page.	Function	Range or Selection	Factory Setting
	Password	0000 to 9998	1000
1	Change Password	No / Yes	No
1.1	New Password	0000 to 9998	1000
2	Channel Selection for MRJ4M-SL	2CH / 6CH	2CH
3	Network Selection	3P4W, 1P2W-P1, 1P2W-P2, 1P2W-P3.	3P4W
4	CT Secondary	Preset	5
5	CT Primary 1 for MRJ4M-SL	5A to 10,000A	160
6	CT Primary 2	5A to 10,000A	160
7	PT Secondary	100V to 500V	350
8	PT primary	100V to 10kV	350
9	Slave Id	1 to 255	1
10	Baud Rate	300, 600, 1200, 2400, 4800, 9600 and 19200	9600
11	Parity	None, Even, Odd	None
12	Stop Bit	1 or 2	1

13 Back Light 0 to 7200 sec.	0000 Sliding
	Sliding
14 Demand interval method Sliding / Fixed	Ŭ,
15 Demand interval duration 1 to 30	15
16 Demand interval length 1 to 30min	1
17 * Pulse Weight (load 1) for MRJ4M-SL 0.01 to 9.99kWh	0.10
18 * Pulse Weight (load 2) 0.01 to 9.99kWh	0.10
19* Pulse Duration 0.1 to 2.0 sec.	0.1
20 Factory Default No / Yes	No
21 Reset Energy and Max Demand No / Yes	No
21.1 Password 0001 to 9999	1001
21.01 Reset Active Energy No / Yes	No
21.02 Reset Reactive Energy No / Yes	No
21.03 Reset Max Power No / Yes	No
For MRJ4M-SL	
•21.1 Password 0001 to 9999	1001
21.01 Reset Active Energy -1 No / Yes	No
21.02 Reset Reactive Energy -1 No / Yes	No
21.03 Reset L1 Max Power No / Yes	No
21.04 Reset Active Energy -2 No / Yes	No
21.05 Reset Reactive Energy -2 No / Yes	No
21.06 Reset L2 Max Power No / Yes	No

 For resetting energy parameters user will be prompted the password. If correct password is entered, the user will be able to reset all energy parameters. This password will be value which will be greater than the configuration password by 1.

* In MRJ4M-SL valid only for 2 channel selection

LEFT HAND CT MOUNTING PHASE CORRECTION

The meter phases L1, L2 & L3 are setup as default for the CT to be mounted as an incomer or on the RHside of the board.

Meter display shows rH when ", " is pressed for 3 sec. When the CT is mounted on the LH side of the board the phase sequence needs to be reversed.

- 1. Press "실" for seconds, then release and then press again for 3 sec. Phase will be reversed and display
- will show LH 2. Wait 5 sec. for meter to resume online reading. Meter display shows LH when "به" is pressed for 3 sec.

MODBUS REGISTER ADDRESSES LIST Readable / writable parameters from MRJ4M / MRJ4M-SL :

40000 40001	0x00			1		(Register)	Structu
	0x00			Min value	Max value		
40001		Password		0	9998	1	Intege
40001				Value	Meaning		
	0x01	N/W selection		0x0000	3P-4W	1	Intege
				0x0002	1P2W-P1	1	Intege
				0x0003	1P2W-P2	1	Intege
Г				0x0004	1P2W-P3	1	Intege
				Min value	Max value		
40002	0x02	CT Secondary (A)		5	5	1	Intege
40003	0x03	CT primary L1 (A)	[load 1 for MRJ4M-SL]	5	10000	1	Intege
40004	0x04	PT Secondary (V)		100	500	1	Intege
40005	0x05	PT primary (V)		100	10000	2	Intege
40007	0x07	Slave id		1	255	1	Intege
				Value	Meaning		
40008	0x08	Baud rate (bps)		0x0000	300	1	Intege
				0x0001	600		
				0x0002	1200		l
				0x0003	2400		
				0x0004	4800		
				0x0005	9600		
		-		0x0006	19200		
40009	0x09	Parity		0x0000	None	1	Intege
				0x0001	Odd		
		0		0x0002	Even		
40010	0010 0x0A Stop bit			0x0000	1	1	Intege
				0x0001	2		
		-		Min value	Max value		
40011	0x0B	Backlight OFF (se	c.)	0	7200	1	Intege
10010		Factor Default		Value	Meaning		Late of
40012	0x0C	Factory Default		1	Set to factory setting range	1	Intege
40013	0x0D	Reset kWh	[of load 1 for MRJ4M-SL]	1	Reset Total Active Energy	1	Intege
40015	0x0F	Reset kVArh	[of load 1 for MRJ4M-SL]	1	Reset Total Reactive Energy	1	Intege
40034	0x22	Demand Interval N	lethod	0X0000	Sliding	1	Intege
				0X0001	Fixed		
40035	0x23	Demand Interval D	Juration	MIN Value : 1	MAX Value : 30	1	Intege
40036	0x24	Demand Interval L	ength(min)	MIN Value : 1	MAX Value : 30	1	Intege
40037	0x25	Reset max kW	[of load 1 for MRJ4M-SL]	1	Reset max Active power	1	Intege
40041	0x29	Reset max kVA	[of load 1 for MRJ4M-SL]		Reset max Apparent power	1	Intege
40042	0x23	Reset kWh	[of load 2 for MRJ4M-SL]		Reset Total Active energy	1	Intege
							-
40044	0x2B	Reset kVArh	[of load 2 for MRJ4M-SL]		Reset Total Reactive energy	1	Intege
40045	0x2C	Reset max kW	[of load 2 for MRJ4M-SL]		Reset max Active power	1	Intege
40049	0x31	Reset max kVA	[of load 2 for MRJ4M-SL]	1	Reset max Apparent power	1	Intege
				Min value	Max value		
40050	0x32	CT primary L2 (A)	[load 2 for MRJ4M-SL]	5	10000	1	Intege
*40057	0x39	Pulse Duration (sec.)		0.1	2.0 (sec.)	1	Intege
[#] 40058	0x3A	Pulse Weight of load 1 (kWh)		0.01	9.99 (kWh)	1	Intege
[#] 40059	0x3B	Pulse Weight (kWl	n)[of load 2 for MRJ4M-SL]	0.01	9.99 (kWh)	1	Intege
	'	U		Value	Meaning		
40060	0x3C	No of Channel		0	2 CH	1	Intege
-10000	0,00			1	6 CH	1	Intege

Doc. name : OP INST MRJ4M / MRJ4M-SL OP386-V03(Page 3 of 4)

MODBUS REGISTER ADDRESSES LIST

Readable parameters : [Length (Register) : 2 ; Data Structure : Float]

NOTE : In 4 byte data type, LSB will be displayed on lower address and MSB will be displayed on higher address

NOTE : I	n 4 byte data typ	pe, LSB will be displayed on lower address			
Address	Hex Address	Parameter			
30000	0x00	Voltage V1N			
30002	0x02	Voltage V2N			
30004	0x04	Voltage V3N			
30006	0x06	Average Voltage LN			
30008	0x08	Voltage V12			
30010	0x0A	Voltage V23			
30012	0x0C	Voltage V31			
30014	0x0E	Average Voltage LL			
30132	0x84	Serial No (Data Structure : Hex)			
For MRJ	For MRJ4M and MRJ4M-SL [Load 2] parameters				
30016	0x10	Current I1			
30018	0x12	Current I2			
30020	0x14	Current I3			
30022	0x16	Average Current			
30024	0x18	kW1			
30026	0x1A	kW2			
30028	0x1C	kW3			
30030	0x1E	kVA1			
30032	0x20	kVA2			
30034	0x22	kVA3			
30036	0x24	kVA5			
30038	0x26	kVAr2			
30040	0x28	kVAr3			
30042	0x2A	Total kW			
30044	0x2C	Total kVA			
30046	0x2E	Total kVAr			
30048	0x30	PF1			
30050	0x32	PF2			
30052	0x34	PF3			
30054	0x36	Average PF			
30056	0x38	Frequency			
30058	0x3A	kWh			
30062	0x3E 0x40	kVArh			
30064 30072	0x40 0x48	kW MAX Active Power			
30134	0x48 0x86	kVA MAX Apparent Power Existing kW MAX Active Power			
30134	0x8A	Existing kVA MAX Apparent Power			
*30142	0x8E	Existing kVA MAX Apparent Power			
	* NOTE : These addresses are valid only for MRJ4M.				

oat]	Dat]						
IND MSB will be displayed on higher address.							
	Address	s Hex Address Only for MRJ4M-SL[Load 1] Parameter					
30074 0>		0x4A	Current I1				
30076 0x4C		0x4C	Current I2				
30078 0x4E		0x4E	Current I3				
30080 0>		0x50	Average Current				
	30082	0x52	0x52 kW1				
	30084	0x54	kW2				
	30086	86 0x56 kW3					
	30088	0x58	kVA1				
	30090 0x5A kVA2		kVA2				
	30092	30092 0x5C kVA3					
	30094 0x5E kVAr1		kVAr1				
	30096	0x60	kVAr2				
	30098 0x62 kVAr3		kVAr3				
	30100	0x64	Total kW				
	30102	0x66	Total kVA				
	30104	0x68	Total kVAr				
	30106	0x6A	PF1				
	30108	0x6C	PF2				
	30110	0x6E	PF3				
	30112	0x70	Average PF				
	30114	0x72	Frequency				
	30116	0x74	kWh				
	30120	0x78 kVArh					
	30122	0122 0x7A kW MAX Active Power					
	30130	30130 0x82 kVA MAX Apparent Power					
	30142 0x8E Total kWh (Load 1 and Load 2)		Total kWh (Load 1 and Load 2)				
	30144	0x90	Total kVArh (Load 1 and Load 2)				
	30146	0x92	Existing kW MAX Active Power				
	30148	0x94	Existing kVA MAX Apperant Power				
	FOR MRJ4M-SL 6 CHANNEL ONLY						
	30150	0x96	kWh of CH1				
	30152	0x98	kWh of CH2				
	30154	0x9A	kWh of CH3				
	30156	0x9C	kWh of CH4				
	30158	0x9E	kWh of CH5				
	30160	0xA0	kWh of CH6				
	30162	0xA2	kVArh of CH1				

Address	Hex Address	Parameter	
30164	0xA4	kVArh of CH2	
30166	0xA6	kVArh of CH3	
30168	0xA8	kVArh of CH4	
30170	0xAA	kVArh of CH5	
30172	0xAC	kVArh of CH6	
30174	0xAE	kW Max active power of CH1	
30176	0xB0	kW Max active power of CH2	
30178	0xB2	kW Max active power of CH3	
30180	0xB4	kW Max active power of CH4	
30182	0xB6	kW Max active power of CH5	
30184	0xB8	kW Max active power of CH6	
30186	0xBA	kVA Max apparent power of CH1	
30188	0xBC	kVA Max apparent power of CH2	
30190	0xBE	kVA Max apparent power of CH3	
30192	0xC0	kVA Max apparent power of CH4	
30194	0xC2	kVA Max apparent power of CH5	
30196	0xC4	kVA Max apparent power of CH6	
30198	0xC6	Existing kW Max active power of CH1	
30200	0xC8	Existing kW Max active power of CH2	
30202	0xCA	Existing kW Max active power of CH3	
30204	0xCC	Existing kW Max active power of CH4	
30206	0xCE	Existing kW Max active power of CH5	
30208	0xD0	Existing kW Max active power of CH6	
30210	0xD2	Existing kVA Max apparent power of CH1	
30212	0xD4	Existing kVA Max apparent power of CH2	
30214	0xD6	Existing kVA Max apparent power of CH3	
30216	0xD8	Existing kVA Max apparent power of CH4	
30218	0xDA	Existing kVA Max apparent power of CH5	
30220	0xDC	Existing kVA Max apparent power of CH6	

APPLICATION OF PULSE OUTPUT PROCESS INTEGRATION . Р L c ⊣⊢ 24V DC Note : This application is also applicable for Pulse output 1. maximum # Valid for MR.I4M-SI + -CT Input RS485 NC 1 2 PULSE OUTPUT Voltage I/F Voltage O/P N V1 V2 V3 O O O O V3 V2 V1 N Ø Ø Ø Ø Valid for MRJ4M-SL 2 1 Ν L3 L2 L1 LINE LOAD

Pulse output from MRJ4M / MRJ4M-SL meter can be interfaced into a process through a PLC for on line control of energy content in the process. If the PLC has a self excited digital input, external DC supply is not needed. The kWh pulse is also used to derive average kWh information at the PLC.

 # All fuse types : 0.5A class CC UL type 0.5A fast acting 600V
 In MRJ4M-SL valid only for 2 channel selection

(Specifications subject to char	nge as development is a	continuous process.)
---------------------------------	-------------------------	----------------------

Selec Controls Pvt. Ltd., India Factory Address : EL-27/1, Electronic Zone, TTC Industrial Area, MIDC, Mahape, Navi Mumbai - 400 710, INDIA. Tel. No. : +91-22-28476443 / 1882 Fax No. : +91-22-28471733 I Toll free : 1800 227 353 Website: www.selec.com I Email: sales@selec.com

Doc. name : OP INST MRJ4M / MRJ4M-SL OP386-V03(Page 4 of 4)