# selec

OP685-V01



# FEATURES

- Leakage current monitoring in 1Ø and 3Ø systems
- RMS value measurement (AC)
- CBCT detection
- User selectable Power ON Delay, Trip Delay and Recovery Delay
- Adjustable hysteresis
- Pre-alarm indication selectable
- Test and Reset via Front / Remote
- Trip relay with NO or NC operation selectable

## SPECIFICATIONS

#### HMI

3 Digits, Seven Segment Display

#### ELECTRICAL CONNECTION 1Ø-2 wire, 3Ø-4 wire, 3Ø-3 wire

AUXILIARY SUPPLY 90-270VAC/DC

#### FREQUENCY RANGE 50 - 60Hz

# VA RATING

4VA max

#### DISPLAY CURRENT RANGE : 15mA - 33A

#### **TRIP SETTING**

Leakage Current Range : 30mA - 30A

#### INSTANTANEOUS TRIP FOR CURRENT ON / OFF (5 times of set current)

#### TIME SETTING

ELR-341-1

Operating Instructions

- Power ON Delay: 1 999secTrip time delay: 0 999secRecovery Time: 1 99minResponse Time:< 30ms (if trip current</td>5 x set value &Instantaneous trip is ON)< 50ms (if trip current = 1 x set value)</td>
- \* For 30mA range, trip time will not be applicable, only response time will be applicable.

#### HYSTERESIS

5 to 40% {For eg., If set HYS is 10% & SV is 100mA; unit will allow untrip at 90mA}

#### RESOLUTION

Depends on trip setting resolution will be, 33mA = 0.1mA 550mA = 1mA 5.50A = 0.01A30A = 0.1A

### **CBCT DETECTION**

Yes, when CBCT absent or short

#### ACCURACY

Current : ±5% of Setting Time : ±5% of Setting±100ms

#### OUTPUT SPECIFICATIONS Relay : 1C/O (SPDT)

#### **RELAY RATING**

NO (5A, 250V AC/28VDC) NC (5A, 250V AC/28VDC)

#### LED INDICATION

LED1 (Red) : mA indication ('ON' only when mA range is displayed) LED2 (Red) : Relay (Continuously ON after trip & blinking for alarm)

#### **RESET CONDITIONS**

- Power ON reset
- Terminal reset (Y1 & Y2 short)
- Press RST key for 3 sec.
- Auto reset (as per setting)

#### **TEST/RESET FUNCTION**

Test / Reset function is used to check proper functioning of product. It includes

- Relay contact switching
- LED check

#### TEST MODE

- Press TST key for 3 sec.
- Test through terminal (Y1 & Y2 short)

#### RESET MODE

- Press RST key for 3 sec.
- Reset through terminal (Y1 & Y2 short)

# ENVIRONMENTAL SPECIFICATIONS

- Indoor use - Altitude of up to 2000 meters
- Pollution degree II
- Temperature : Operating : 0 to 55°C
- Storage : -20 to 70°C
- Humidity : Up to 95% RH, non-condensing

#### MECHANICAL SPECIFICATIONS

No. of Push Buttons : 3 Size : 96 x 96 mm Mounting : Panel Mount Wire Size (max) : 4 sq.mm Screw tightening torque : 0.5 N-M

#### WEIGHT : 290gm approx.

LED INDICATION CHART				
Various Conditions	'mA' LED	'R' LED		
No fault	OFF*	OFF		
Trip	OFF*	ON		
Pre-Alarm	OFF*	Blinking		
CBCT error	OFF*	ON		

\* = 'ON' only when 33mA / 550mA range is selected.

ORDER CODE INFORMATION					
PRODUCT SUPPLY CERTIFICATION					
		CE	UL		
ELR-341-1	230V AC	—	—		

# **TERMINAL CONNECTIONS**



# Prote For Connection

For single phase applications, only the live and neutral needs to be passed through the CBCT. The Earth MUST NOT pass through the CBCT. The distance between relay and CBCT should be kept as short as possible Use screen, shielded cable or twisted pair cable between the unit and CBCT for long distance (Greater than 1m).

#### **CONFIGURATION MENU**

#### Press $A + \forall$ for 3sec. to enter or exit configuration menu.

Press  to save value				
	Press ▲ or ▼ to scroll Press ● + ▲ or ● + ¥ to change hrough menu		nge parameter value	
DISPLAY (For 1sec)	DESCRIPTION	DEFAULT VALUE	RANGE	CONDITION
P.00	Power ON Delay		1 to 999sec	
- NG	Range Selection	5.50	33.0, 550, 5.50, 30.0	Depending upon this selection, the set trip value will be prompted. If this setting is changed the default trip value is loaded. 'OVR' will be displayed; if input current is greater than selected Range.
5	Set Trip Value	100	SV can be programmed between 30mA to 30A irrespective of the selected range. Default SV for different ranges are : 33.0 : 30.0mA 550 : 100mA 5.50 : 1.00A 30.0 : 10.0A	If SV exceeds max limit of specified range then next range will automatically be made applicable. For eg.If SV is set 40mA, range will get changed from 33mA to 550mA automatically.
18	Instantaneous Trip Selection	ПО	ON / OFF (5 times of set current)	If INS = ON and leakage current $\geq$ 5 times the set value, the relay trips instantaneously irrespective of trip time delay.
ErP	Trip Time Delay	-	0-999sec	(Not Applicable for 33mA range)
-EE	Recovery Time Delay	5	1-99Min	
PrE	Pre-Alarm	d 15	ENABLE / DISABLE	
	i-ie-Alaiiii	582	50 to 100%	This option will be prompted only if Pre-alarm enabled
-nDd	Relay Operation Mode	ПП	ON / OFF (For ON mode, contact will be in changed over state in normal condition).	
LEH	Latch	OFF	ON / OFF	If latch is ON, user has to reset the unit manually when fault is removed

HY5	Hysteresis	10	5 to 40%	
r 5E	Reset	ПО	YES / NO	

TEST & RESE	T FUNCTION			● LED ON ◯ LED OFF
KEY	DESCRIPTION	DISPLAY (For 1sec.)	LED's	CONDITION
For TEST	Press TST key for 3 Sec.	ESE	O O mA R	Test function is applicable only when unit is in healthy condition.
Test passed		02	● ● mA R	If test is passed, OK will be displayed till reset button is pressed.
Test Failed		חסה	O O mA R	
RST	Press RST key for 3 Sec.	Actual Value	O O mA R	If current is in mA then "mA" LED will be ON.
RESET	Press V ke	y for 3sec. to r	eset manı	Jally.
TRIP VALUE	On 🔺 key p	ress : Trip valu	ue will be	displayed till the key is pressed.
In configuration menu, if no key pressed for 30 sec. then unit resumes online mode.				

# WARRANTY / LIMITATIONS OF LIABILITY

Selec warrants the products to be free from defects in the materials and workmanship for a period of one year (or other period specified, if any) from the date of sale by Selec.

The warranty does not apply to defects resulting from any action of the buyer, including but not limited to improper handling, operating the product outside the specification limits or unauthorized disassembling / altering of the product. The warranty shall be VOID if the product shows evidence of having been tampered or being damaged due to usage in corrosive environment; or current, heat, moisture or vibration; improper specification; wrong usage in an application misuse or other operating conditions outside of Selec's control.

Selec shall not be responsible for special, indirect or consequential damages, loss of profits or commercial loss in any way connected with the products, whether such claim is based on contract, warranty, negligence or strict liability.

In no event shall the responsibility of Selec for any act exceed the individual price of the product on which liability is asserted.

In no event shall Selec be responsible for warranty or other claims regarding the products unless Selec's analysis confirms that the products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification or repair.

# SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

If there is physical damage to the unit then do not use it.

Read complete instructions prior to installation and operation of the unit.

# WIRING GUIDELINES

#### **3** WARNING

1. To prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement.

2. Wiring shall be done strictly according to the terminal layout with shortest connections. Confirm that all connections are correct.

# CAUTION

1. To ensure the safe operation of unit, check the wiring and connections.

#### **CT DIMENSIONS**

CORE BALANCED CURRENT TRANSFORMER



СВСТ	Dimensions (mm)					
TYPE	D	d	h	w		
35-1	52.50	38	40	4		
70-1	87	38	40	4		
120-1	122	38	40	4		
210-1	199.80	120	55	6.60		
310-1	300	200	66	6.60		
TOLERANCE	Linear Tolerance : ±0.1mm					

Linear Iolerance : ±0.1mm



СВСТ	Dimensions (mm)					
TYPE	D	d	Н	W	W1	
35-1	71.30	35	97	15	40	
70-1	107.50	70	133	15.50	40	
120-1	158	120	184.50	15.50	40	
210-1	268	210	270	25	55	
310-1	377	310	379	25.50	65	
TOLERANCE	TOLERANCE Linear Tolerance : ±0.1mm					
CT TYPE ZPC (Zero Phase Current)						
MECHANICAL SPECIFICATIONS						
OUTLINE Dimensions (in mm)				NEL CUTO ensions (in		









WARRANTY / LIMITATIONS OF LIABILITY

Selec warrants the products to be free from defects in the materials and workmanship for a period of one year (or other period specified, if any) from the date of sale by Selec.

The warranty does not apply to defects resulting from any action of the buyer, including but not limited to improper handling, operating the product outside the specification limits or unauthorized disassembling / altering of the product. The warranty shall be VOID if the product shows evidence of having been tampered or being damaged due to usage in corrosive environment; or current, heat, moisture or vibration ; improper specification ; wrong usage in an application misuse or other operating conditions outside of Selec's control.

Selec shall not be responsible for special, indirect or consequential damages. loss of profits or commercial loss in any way connected with the products, whether such claim is based on contract, warranty, negligence or strict liability.

In no event shall the responsibility of Selec for any act exceed the individual price of the product on which liability is asserted.

In no event shall Selec be responsible for warranty or other claims regarding the products unless Selec's analysis confirms that the products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification or repair.

(Specifications subject to change as development is a continuous process.)

Selec Controls Pvt. Ltd., India

Factory Address : EL-27/1. Electronic Zone. TTC Industrial Area. MIDC, Mahape, Navi Mumbai - 400 710, INDIA. Tel. No. : +91-22-28476443 / 1882 Fax No.: +91-22-28471733 | Toll free: 1800 227 353 Website: www.selec.com I Email: sales@selec.com